

Figure 5-1. Type WJ-8615D VHF/UHF Compact Receiver, Front View
Location of Components






Figure 5-2. Type WJ-8615D VHF/UHF Compact Receiver, Rear View
Location of Components



* DENOTES OPTIONAL COMPONENT

Figure 5-3. Type WJ-8615D VHF/UHF Compact Receiver, Top View
Location of Components



✱ DENOTES HIDDEN COMPONENT

Figure 5-4. Type WJ-8615D VHF/UHF Compact Receiver, Bottom View
Location of Components