

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
5805-00-224-3825	TFC-212	CONV, FREQ, ELECT		F	1075
5805-00-410-5146	SST-1045	CONV, FREQ, ELECT	CV-3286/UR		
5805-00-978-6350	VOR-6	CHAN SHIFTER, VOICE			
5805-01-132-9040	EC-168	EXTENDER CARD,ELEC			
5811-00-168-3518	EC-205	EXTENDER CABLE			
5811-00-224-3817	TFC-101	CONV, FREQ, ELECT		F	1075
5811-00-256-7944	MC-105	CONTROL UNIT, MSTR			
5811-00-489-4516	VH-13	TUNING UNIT, RF	TN-532/GR	S	0876
5811-00-489-4516	VH-13	TUNING UNIT, RF	TN-532/GR	S	0876
5811-01-011-8070	DM-212A	DEMODULATOR			
5811-01-015-9824	WJ-8947	TUNER GROUP, MICRO			
5811-01-087-8297	WJ-9525/CRF	PWR SUPPLY/AMPL	PP-7639/G	S	0680
5811-01-087-8297	WJ-9525/CRF	PWR SUPPLY/AMPL	PP-7639/G	S	0680
5811-01-087-8297	WJ-9525/CRF	PWR SUPPLY/AMPL	PP-7639/G	S	0680
5811-01-087-8298	WJ-9525/CU	CONTROL UNIT	C-10827/G	S	0680
5811-01-087-8298	WJ-9525/CU	CONTROL UNIT	C-10827/G	S	0680
5811-01-087-8298	WJ-9525/CU	CONTROL UNIT	C-10827/G	S	0680
5811-01-088-0549	WJ-9525	DEMULTIPLEXER	TD-1323(V)1/G		
5811-01-088-6729	WJ-9525/DU	DEMULTIPLEXER	TD-1324/G	S	0680
5811-01-088-6729	WJ-9525/DU	DEMULTIPLEXER	TD-1324/G	S	0680
5811-01-088-6729	WJ-9525/DU	DEMULTIPLEXER	TD-1324/G	S	0680
5811-01-089-5851	WJ-9525	DEMULTIPLEXER	TD-1323(V)1/G	S	0680
5811-01-089-5851	WJ-9525	DEMULTIPLEXER	TD-1323(V)1/G	S	0680
5811-01-089-5851	WJ-9525	DEMULTIPLEXER	TD-1323(V)1/G	S	0680
5811-01-202-1152	WJ-9471/CRF24				
5811-01-202-1168	WJ-9472/DU	DEMODULATOR			
5811-01-202-1169	WJ-9471/DU	DEMODULATOR			
5811-01-362-7014	WJ-9949-1	SPEAKER PANEL			
5815-00-251-1909	TDM-102	DEMODULATOR			
5815-00-251-1910	TDM-101	DEMODULATOR		F	1075
5815-00-262-1047	TDM-102-1	DEMODULATOR			
5820-00-006-2758	MC-105-2	CONTROL UNIT	C-9171/GR	F	1071
5820-00-006-2759	MC-105-3	CONTROL UNIT	C-9172/GR	F	1071
5820-00-008-2333	205-2	RECEIVER, RADIO	R-1723A(P)/GR	F	0371
5820-00-008-2334	SM-7301A	INDICATOR, PAN	IP-1059A/GR	S F	0876
5820-00-008-2334	SM-7301A	INDICATOR, PAN	IP-1059A/GR	S F	0876
5820-00-070-7967	FE-25-1	CONV, FREQ, ELECT	CV-1750/U	S	0566

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
5820-00-070-7967	FE-25-1	CONV, FREQ, ELECT	CV-1750/U	S	0566
5820-00-104-2611	770A	RECEIVER, RADIO	R-1470/URR		
5820-00-104-2621	960B	RECEIVER, RADIO	R-1279B/URR		
5820-00-104-2649	970A	RECEIVER, RADIO	R-1468/URR		
5820-00-105-3064	SM-8512	INDICATOR, PAN	IP-861/URR	F	0273
5820-00-107-1471	905	RECEIVER, RADIO		S	
5820-00-110-8160	SST-1045A	CONV, FREQ, ELECT		F	0873
5820-00-116-4988	978A	RECEIVER, RADIO	R-1595/UR	S	0968
5820-00-116-4988	978A	RECEIVER, RADIO	R-1595/UR	S	0968
5820-00-116-4989	416-12	RECEIVER, RADIO	R-1596/UR	S	0968
5820-00-116-4989	416-12	RECEIVER, RADIO	R-1596/UR	S	0968
5820-00-122-8781	SM-4301A	INDICATOR, PAN	IP-958/UR	S	0968
5820-00-122-8781	SM-4301A	INDICATOR, PAN	IP-958/UR	S	0968
5820-00-136-1922	521A	RECEIVER, RADIO	R-1625/UR	S	0169
5820-00-136-1922	521A	RECEIVER, RADIO	R-1625/UR	S	0169
5820-00-136-8451	357-1	RECEIVER, RADIO	R-1401B/G		
5820-00-137-7803	DM-4	DEMODULATOR			
5820-00-137-7806	IFD-4000C	DEMODULATOR, IF			
5820-00-139-3660	IFD-210-1	DEMODULATOR, IF			
5820-00-139-3663	TDM-110	DEMODULATOR			
5820-00-139-3664	AM-105	PANEL. MONITOR			
5820-00-140-9686	ST-1045	TUNER, RF			
5820-00-140-9687	CT-4080	CONV FREQ ELECT			
5820-00-145-2594	907	RECEIVER, RADIO			
5820-00-168-4320	DRX-1000	CONV, FREQ, ELEC		F	0873
5820-00-185-7047	PD-602	DISPLAY, PANORAMIC			
5820-00-185-7047	PD-602-3	DISPLAY UNIT	IP-1126/GR	F	1071
5820-00-190-2245	RS-125	RECEIVER, RADIO			
5820-00-193-3358	RS-111-1B-12	RECEIVER, RADIO			
5820-00-195-4378	357-8	RECEIVER, RADIO	R-1687/G	S	0670
5820-00-195-4378	357-8	RECEIVER, RADIO	R-1687/G	S	0670
5820-00-221-3467	GDM-1	DEMODULATOR			
5820-00-227-7350	965	RECEIVER, RADIO	R-1521/UR	S	0767
5820-00-227-7350	965	RECEIVER, RADIO	R-1521/UR	S	0767
5820-00-229-1780	SM-6108	INDICATOR, PAN		F	1074
5820-00-230-7117	DM-112	DEMODULATOR		F	1075
5820-00-231-8149	SVT-30B	CONV, FREQ, ELECT			

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
5820-00-231-8151	SUT-1000B	CONV, FREQ, ELECT			
5820-00-238-0447	555-1	RECEIVER, RADIO		F	0573
5820-00-241-1649	TFC-210	CONV, FREQ, ELECT			
5820-00-241-1650	112	RECEIVER, RADIO	R-1811/GR	F	1071
5820-00-241-1652	TH-240A	TUNING UNIT, RF	TN-548/GR	F	1071
5820-00-249-6612	SM-9404A	INDICATOR, PAN	IP-1206/UR	F	0773
5820-00-268-3990	HH-11	TUNER, RF			
5820-00-279-5820	FT-203	CONV, FREQ, ELECT	CV-3259/UR	F	0774
5820-00-286-1661	CSU-160	TUNER SWITCH UNIT		S F	0876
5820-00-286-1661	CSU-160	TUNER SWITCH UNIT		S F	0876
5820-00-286-1662	SM-8421	INDICATOR, PAN	IP-1207/UR	F	0774
5820-00-319-0459	FE-103	CONV, FREQ, ELEC	CV-1983/URR	S	0566
5820-00-319-0459	FE-103	CONV, FREQ, ELEC	CV-1983/URR	S	0566
5820-00-321-5211	RS-111-1B-2	RECEIVER, RADIO			
5820-00-332-8081	354	RECEIVER, RADIO			
5820-00-342-1815	EC-101B	CABLE ASSEMBLY SPEC	CX-10684/UR		
5820-00-357-3877	R486-31	RECEIVER, RADIO	R-1891/GRR-34(V)		
5820-00-357-3878	R489-7	RECEIVER, RADIO	R-1892/GRR-34(V)		
5820-00-357-3879	R490-7	RECEIVER, RADIO	R-1893/GRR-34(V)		
5820-00-360-0084	DRO-280	COUNTER, FREQ			
5820-00-360-0085	EF-182	EQUIPMENT FRAME	MT-4643/GRR-34(V)		
5820-00-360-5331	RS-111-1B-35	RECEIVER, RADIO			
5820-00-366-0215	R485-21	RECEIVER, RADIO	R-1890/GRR-34(V)		
5820-00-366-0232	EF-180	EQUIPMENT FRAME	MT-4642/GRR-34(V)		
5820-00-378-1486	RS-111-1B-12B	RECEIVER, RADIO	AN/URR-52B	S	0574
5820-00-378-1486	RS-111-1B-12B	RECEIVER, RADIO	AN/URR-52B	N	0383
5820-00-401-5972	TH-480A	TUNING UNIT, RF	TN-549/GR	F	1071
5820-00-403-1938	SM-9304A	INDICATOR, PAN		F	0873
5820-00-404-0930	AGC-BC/B	AUTO GAIN CONTROL	PL-1185/UR	S	0567
5820-00-404-0930	AGC-BC/B	AUTO GAIN CONTROL	PL-1185/UR	S	0567
5820-00-405-6241	IFD-100C	DEMODULATOR, IF			
5820-00-405-6242	IFD-500C	DEMODULATOR, IF	P10-972/OR	F	0774
5820-00-405-6243	IFD-1000C	DEMODULATOR, IF	MD-973/UR	F	0873
5820-00-405-6244	DM-4C	DEMODULATOR			
5820-00-405-6245	IFD-8000C	DEMODULATOR, IF	P10-979/OR		
5820-00-405-6251	DRO-312	COUNTER, FREQ			
5820-00-407-2147	S-9903D	PANEL, MONITOR	SB-3553/G	S	0870

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
5820-00-407-2147	S-9903D	PANEL, MONITOR	SB-3533/G	S	0870
5820-00-408-8837	SM-7301	INDICATOR, PAN	IP-1059/GR	S	0870
5820-00-408-8838	VH-11	TUNING UNIT, RF	TN-530/GR	F	0371
5820-00-408-8839	VH-12	TUNING UNIT, RF	TN-531/GR	F	0371
5820-00-408-8841	UH-11	TUNING UNIT, RF	TN-534/GR	S F	0876
5820-00-408-8841	UH-11	TUNING UNIT, RF	TN-534/GR	S F	0876
5820-00-408-8842	UH-12	TUNING UNIT, RF	TN-535/GR	S F	0876
5820-00-408-8842	UH-12	TUNING UNIT, RF	TN-535/GR	S F	0876
5820-00-409-5667	VH-14	TUNING UNIT, RF	TN-533/GR	S F	
5820-00-409-5667	VH-14	TUNING UNIT, RF	TN-533/GR	S F	0876
5820-00-410-5147	SCT-4080	TUNING UNIT, RF	CV-3285/UR	F	0837
5820-00-410-5148	SXT-8012	CONV, FREQ, ELECT			
5820-00-422-8983	113	RECEIVER, RADIO	R-1812/GR	F	1071
5820-00-422-8985	114	RECEIVER, RADIO	R-1810/GR	F	1071
5820-00-422-8993	TH-120	TUNING UNIT, RF			
5820-00-422-8994	TH-812	TUNING UNIT, RF			
5820-00-431-9635	SM-1622	INDICATOR, PAN	IP-1125/GR	F	1071
5820-00-431-9636	DRX-308	CONV, FREQ, ELEC	CV-2919/GR	F	0371
5820-00-431-9637	TSU-160	TUNING SWITCH UNIT	TN-540/GR	F	0371
5820-00-434-0659	205	RECEIVER, RADIO	R-1723(P)/GR	S	0770
5820-00-449-3360	DRO-302A	COUNTER, FREQ	CP-1057/G		
5820-00-451-2966	RD-101	INDICATOR, DIG, OSPY	ID-1736/GLA.	A	1269
5820-00-455-1041	SWP-104	PANEL, SWITCHING			
5820-00-477-3654	775-9	RECEIVER, RADIO	R-1971/UR	F	0773
5820-00-481-7057	MT-112	TUNER, MICROWAVE			
5820-00-482-2571	AGC-PS/CA	AUTO GAIN CONTROL			
5820-00-487-0174	SM-9804A	INDICATOR, PAN	IP-991/UR	S	0469
5820-00-487-0174	SM-9804A	INDICATOR, PAN	IP-991/UR	S	0469
5820-00-489-7468	SWP-602	SWITCHING UNIT	SA-2045/UR	F	0774
5820-00-491-0461	DMS-105A-2	DEMODULATOR	MD-967/UR	F	0273
5820-00-499-1706	355-1				
5820-00-524-2319	IFD-5CA	DEMODULATOR, IF	MD-967/UR	F	0774
5820-00-524-2322	IFD-15CA	DEMODULATOR, IF	MD-968/UR	F	0774
5820-00-524-2325	IFD-50CA	DEMODULATOR, IF	P10-969/OR	F	0774
5820-00-524-2328	IFB-100CA	DEMODULATOR, IF	MD-970/UR	F	0774
5820-00-524-2332	IFD-200C	DEMODULATOR, IF	MD-971/UR	F	0774
5820-00-524-2333	IFD-2000C	DEMODULATOR, IF	P10-972/OR	F	0774

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
5820-00-524-2334	DM	DEMODULATOR	MD	F	0774
5820-00-524-2336	SP-101C	RACK, STORAGE	MT-4757/UR		
5820-00-524-2337	S-9203A	PANEL, MONITOR	SB-3808/UR	F	0774
5820-00-524-2344	VT-11	CONV, FREQ, ELECT	CV-3258/UR	F	0774
5820-00-534-9814	DRO-302B	COUNTER, FREQ	CP-1206/UR	S	1173
5820-00-557-4329	AGC-PS/C	AUTO GAIN CONTROL			
5820-00-557-4330	977-1	RECEIVER, RADIO	R-1972/UR	F	0769
5820-00-558-2494	373A-2	RECEIVER, RADIO		S	0378
5820-00-605-4567	TH-812C	TUNING UNIT, RF	P/00A-8899/GRR	F	1175
5820-00-605-4568	TH-145C	TUNER			
5820-00-824-9937	LT-1020A	CONV, FREQ, ELECT	CV-2382/UR	S	0567
5820-00-824-9937	LT-1020A	CONV, FREQ, ELECT	CV-2382/UR	S	0567
5820-00-824-9938	STS-2045	CONV, FREQ, ELECT	CV-2383/UR	S	0567
5820-00-824-9938	STS-2045	CONV, FREQ, ELECT	CV-2383/UR	S	0567
5820-00-824-9939	UT-1000B	CONV, FREQ, ELECT	CV-2384/UR	S	0667
5820-00-824-9939	UT-1000B	CONV, FREQ, ELECT	CV-2384/UR	S	0667
5820-00-828-1839	SM-9401C	INDICATOR, PAN	IP-893/UR		0567
5820-00-828-1839	SM-9401C	INDICATOR, PAN	IP-893/UR		0567
5820-00-828-1846	TF-202	CONV, FREQ, ELECT	CV-2386/UR	S	0667
5820-00-828-1846	TF-202	CONV, FREQ, ELECT	CV-2386/UR	S	0667
5820-00-828-1848	DM-4B	DEMODULATOR	MD-753(P)/UR	S	0567
5820-00-828-1848	DM-4B	DEMODULATOR	MD-753(P)/UR	S	0567
5820-00-828-1850	IFD-5B	DEMODULATOR, IF	P10-754/OR	S	0567
5820-00-828-1850	IFD-5B	DEMODULATOR, IF	MD-754/UR	S	0567
5820-00-828-1851	IFD-15BA	DEMODULATOR, IF	MD-755/UR	S	0567
5820-00-828-1851	IFD-15BA	DEMODULATOR, IF	MD-755/UR	S	0567
5820-00-828-1854	IFD-50BA	DEMODULATOR, IF	MD-756/UR	S	0567
5820-00-828-1854	IFD-50BA	DEMODULATOR, IF	MD-756/UR	S	0567
5820-00-828-1855	IFD-200B	DEMODULATOR, IF	MD-757/UR	S	0567
5820-00-828-1855	IFD-200B	DEMODULATOR, IF	MD-757/UR	S	0567
5820-00-828-6547	IFD-500B	DEMODULATOR, IF	MD-758/UR	S	0567
5820-00-828-6547	IFD-500B	DEMODULATOR, IF	P10-758/OR	S	0567
5820-00-828-6554	IFD-2000B	DEMODULATOR, IF	MD-759/UR	S	0567
5820-00-828-6554	IFD-2000B	DEMODULATOR, IF	MD-759/UR	S	0567
5820-00-828-6556	IFD-4000B	DEMODULATOR, IF	MD-760/UR		
5820-00-828-6557	IFD-8000B	DEMODULATOR, IF	MD-761/UR	S	0567
5820-00-828-6557	IFD-8000B	DEMODULATOR, IF	MD-761/UR	S	0567

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
5820-00-828-6563	DA-1	AMPLIFIER, VIDEO	AM-4890/UR	S	0567
5820-00-828-6563	DA-1	AMPLIFIER, VIDEO	AM-4890/UR	S	0567
5820-00-829-3838	AGC-PS/B	AUTO GAIN CONTROL	PL-1160/UR	S	0767
5820-00-829-3838	AGC-PS/B	AUTO GAIN CONTROL	PL-1160/UR	S	0767
5820-00-829-3840	IFD-1000B	DEMODULATOR, IF	MD-763/UR	S	0567
5820-00-829-3840	IFD-1000B	DEMODULATOR, IF	MD-763/UR	S	0567
5820-00-833-0156	357	RECEIVER, RADIO	R-1401A/G	S	1166
5820-00-833-0156	357	RECEIVER, RADIO	R-1401A/G	S	1166
5820-00-833-6988	VT-30B	CONV, FREQ, ELECT	CV-2385/UR	S	0667
5820-00-833-6988	VT-30B	CONV, FREQ, ELECT	CV-2385/UR	S	0667
5820-00-836-0485	FT-101A	CONV, FREQ, ELECT	CV-2387/UR	S	0567
5820-00-836-0485	FT-101A	CONV, FREQ, ELECT	CV-2387/UR	S	0567
5820-00-848-2545	SM-9801A	INDICATOR, PAN	IP-894/UR	S	0567
5820-00-848-2545	SM-9801A	INDICATOR, PAN	IP-894/UR	S	0567
5820-00-851-4385	DRO-300-3	COUNTER, FREQ	CP-931/G	S	0867
5820-00-851-4385	DRO-300-3	COUNTER, FREQ	CP-931/G	S	0867
5820-00-851-4452	975-2	RECEIVER, RADIO	R-1536/UR	S	0867
5820-00-851-4452	975-2	RECEIVER, RADIO	R-1536/UR	S	0867
5820-00-851-4457	702A	RECEIVER, RADIO	R-1537/UR	S	0867
5820-00-851-4457	702A	RECEIVER, RADIO	R-1537/UR	S	0867
5820-00-875-4440	SM-9301A	INDICATOR, PAN	IP-751A/URR	S	0567
5820-00-875-4440	SM-9301A	INDICATOR, PAN	IP-751A/URR	S	0567
5820-00-875-4447	SM-9801	INDICATOR, PAN			
5820-00-875-4447	SM-9831	INDICATOR, PAN	IP-798/GR		
5820-00-876-6859	DM-160	DEMODULATOR	MD-766/UR	S	0368
5820-00-876-6859	DM-160	DEMODULATOR	MD-766/UR	S	0368
5820-00-887-6542	VHF	RECEIVER	R-1341/GR		
5820-00-889-7306	FE-425	CONV, FREQ, ELECT	CV-25	A	0769
5820-00-933-7909	SM-8512-4	INDICATOR, PAN	IP-866/URR	N	0766
5820-00-946-5661	905A	RECEIVER, RADIO	R-1420/URR		
5820-00-998-9332	901B	RECEIVER, RADIO	R-1394/UR		0567
5820-00-999-8022	RS-111-1B-7	RECEIVER, RADIO	AN/URR-52A	S F	0371
5820-00-999-8022	RS-111-1B-7	RECEIVER, RADIO	AN/URR-52A	S F	0371
5820-00-999-8022	RS-111-1B-7	RECEIVER, RADIO	AN/URR-52A	S	0371
5820-00-999-8023	SM-8511-2	INDICATOR, PAN	IP-833/GRR	N	0366
5820-01-005-4135	NS-101BA	NOISE SILENCER			
5820-01-006-5398	TH-120C	TUNING UNIT, RF	P/00A-8899/GRR	F	1175

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
5820-01-007-4225	AGC-BC/C	AUTO GAIN CONTROL			
5820-01-009-4319	WJ-1240V2	RECEIVING SET, RADIO			
5820-01-017-9734	RS-111-18-12A	RECEIVER, RADIO			
5820-01-018-1676	RS-125-17	RECEIVER, RADIO			
5820-01-023-0237	357-11	RECEIVER, RADIO	R-2056/G		
5820-01-033-5493	XT-8012	TUNER, RF			
5820-01-033-5534	AM-105-2	PANEL. MONITOR			
5820-01-056-4499	FT-222-200	IF TAPE CONV		S	0378
5820-01-058-2676	WJ-8730A	RECEIVER	AN/SSQ-80(V)	S	0378
5820-01-058-2676	WJ-8730A	RECEIVER		S	0378
5820-01-058-2676	WJ-8730A	RECEIVER		S	0378
5820-01-060-4786	WJ-8718//MI	RCVG SET, RADIO	AN/URR-74(V)1	A	1078
5820-01-060-4786	WJ-8718//MI	RCVG SET, RADIO	AN/URR-74(V)1	A	1078
5820-01-071-7703	TF-105	CONVERTER, FREQ			
5820-01-089-7761	WJ-8640	RECEIVER, RADIO			
5820-01-091-7411	TSU-103B	TUNER SWITCH UNIT			
5820-01-091-9335	WJ-9062	TUNING HEAD		S	0378
5820-01-091-9335	WJ-9602	TUNING HEAD		S	0378
5820-01-091-9335	WJ-9602	TUNING HEAD		S	0378
5820-01-095-6809	WJ-9061	TUNING HEAD		S	0378
5820-01-095-6809	WJ-9061	TUNING HEAD		S	0378
5820-01-095-6809	WJ-9061	TUNING HEAD		S	0378
5820-01-123-4566	565	RECEIVER, RADIO			
5820-01-126-9339	UH-104	TUNING HEAD			
5820-01-160-4411	WJ-8975A	DIRECTION FINDER	C-11495/PRD-11		
5820-01-160-4684	AN/TRQ-37	RCVG, SET, RADIO	AN/TRQ-37	A	0185
5820-01-160-4684	AN/TRQ-37	RCVG, SET, RADIO	AN/TRQ-37	A	0185
5820-01-200-0177	WJ-9880A-1	ANTENNA, DF	AS-3733/PRD-11		
5820-01-201-9965	WJ-8975/AS	ANGLE SIMULATOR			
5820-01-203-9916	WJ-390601	SWITCHING UNIT	SA-2494/G	A	0185
5820-01-203-9917	PD-603	INDICATOR, PANORAM	IP-1513/G	A	0185
5820-01-203-9917	PD-603	INDICATOR, PANORAM	IP-1513/G	A	0185
5820-01-203-9920	WJ-8971/AS	SIMULATOR, ANGLE DF	SM-843/G		
5820-01-204-0003	WJ-9895	MAST, ANT, TELESCOP	A8-1333/G	A	0185
5820-01-204-0283	WJ-8617B-5	RECEIVER, RADIO	R-2311/G	A	0185
5820-01-205-0860	WJ-390602	INTERFACE UNIT	J-4339/G	A	0185
5820-01-206-5731	WJ-9068	TUNING HEAD		S	0378

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
5820-01-206-5731	WJ-9068	TUNER, RADIO			
5820-01-206-5731	WJ-9068	TUNING HEAD		S	0378
5820-01-206-5731	WJ-9068	TUNING HEAD		S	0378
5820-01-206-5732	W3-9064	TUNING HEAD		S	0378
5820-01-206-5732	WJ-9064	TUNING HEAD		S	0378
5820-01-206-5732	WJ-9064	TUNING HEAD		S	0378
5820-01-206-5732	WJ-9064	TUNER, RADIO FREQUENCY			
5820-01-206-5733	WJ-9063	TUNER, RADIO FREQUENCY			
5820-01-224-1109	WJ-8790	RECEIVER, RADIO.			
5820-01-828-6566	DTF-101B	TEST MODULE	TS-2606/UR	S	0876
5820-01-828-6566	DTF-101B	TEST MODULE	TS-2606/UR	S	0876
5820-01-828-6566	DTF-101B	TEST MODULE	TS-2606/UR	S	0876
5821-01-123-1743	WJ-8718	RCVG SET, RADIO	AN/URR-74(V)	A	1078
5821-01-153-1216	WJ-8718//UCI	RCVR W/MFP/COR/ISB			
5821-01-419-9809	WJ-8690	RECEIVER, RADIO			
5821-01-441-5568	WJ-8690A/MCR	RECEIVER, RADIO			
5821-01-441-5570	WJ-8690A/DCT	TUNER, RADIO FREQUENCY			
5825-01-186-9465	WJ-9880	ANTENNA, DF			
5825-01-187-0438	WJ-9880-1	ANTENNA			
5825-01-188-3435	AN/PRD-11				
5825-01-203-9915	WJ-390604	INDICATOR UNIT	ID-2381/G	A	0185
5825-01-204-0292	WJ-8971A-6	DF-INDICATOR	ID-2380/G	A	0185
5825-01-204-0292	WJ-8971A-6	DF-INDICATOR	ID-2380/G	A	0185
5825-01-453-6717	WJ-8991/SYS	DIRECTION FINDER SET			
5830-01-204-0006	WJ-8977-2/M	INTERCOM UNIT, MSTR	LS-672/G	A	0185
5830-01-204-0006	WJ-8977-2/M	INTERCOM UNIT, MSTR	LS-672/G	A	0185
5830-01-204-0007	WJ-8977-2/R	INTERCOM UNIT, RMT	LS-673/G	A	0185
5830-01-269-6497	WJ-9470/488				
5835-00-482-2568	FT-210	CONV, FREQ, ELECT	CV-3824/UR	F	0873
5840-01-145-3304	WJ-8718//UC	RCVR W/MFP/COR			
5865-00-254-5138	QRC-259	RECEIVER			
5865-00-254-5138	QRC-259	RECEIVER	QRC-259		
5865-01-003-9482	VH-103	TUNING UNIT, RF		S	1173
5865-01-003-9483	565-6	RECEIVER, RADIO		S	1173
5865-01-114-7570	WJ-8975	DIRECTION FINDER			
5865-01-145-2804	EC-180	EXTENDER CABLE			
5865-01-165-4578	WJ-9880A	ANTENNA	AS-3732		

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
5865-01-271-1540	WJ-4810/JCU	CONTROL, COUNTERMEASURES TRANSMITTING S			
5865-01-284-3216	WJ-4810/CJS004	COMJAM SYSTEM-HF/VHF/UHF	AN/TLQ-504(V)		
5865-01-321-5551	WJ-9195C	PROCESSOR, ACQUISITION SEPCTRUM			
5865-01-329-6025	WJ-8718A	HF RECEIVER	R-5143/TLQ-504(V)		
5865-01-344-3521	WJ-8990	DIRECTION FINDER			
5865-01-392-6005	WJ-4810/JCUA	CONTROL, COUNTERMEASURES TRANSMITTING S	C-5550/TLQ-504(V)		
5865-01-407-5281	WJ-4810/JCUA-1	CONTROL, COUNTERMEASURES TRANSMITTING S			
5875-01-343-7268	W3-9902/FPU/488	RECEIVER FRAME			
5895-00-094-6853	977-5	RECEIVER, RADIO			
5895-00-099-2052	775-13	RECEIVER, RADIO			
5895-00-201-5036	SD-104-4	DEMULTIPLEXER			
5895-00-201-5036	SD-104A-4	DEMULTIPLEXER			
5895-00-201-5042	SD-104-1	DEMULTIPLEXER			
5895-00-201-5042	SD-104A-5	DEMULTIPLEXER			
5895-00-221-3468	EF-511	EQUIPMENT FRAME			
5895-00-237-4721	TF-102	CONV, FREQ, ELECT			
5895-00-237-4727	IFC-21	CONV, FREQ, ELECT			
5895-00-264-1430	FT-201A	CONV, FREQ, ELECT		F	0873
5895-00-270-0966	IFD-103	DEMODULATOR, IF	MD-975/UR	F	0774
5895-00-279-5819	TF-103	CONV, FREQ, ELECT	CV-3260/UR	F	0774
5895-00-294-0134	TFC-105-1	CONV, FREQ, ELECT			
5895-00-303-3786	HT-10	CONV, FREQ, ELECT	CV-3257/UR	F	0774
5895-00-307-5774	TFC-105	CONV, FREQ, ELECT			
5895-00-394-5825	VT-10	CONV, FREQ, ELECT			
5895-00-436-0054	FE1-4.5	CONV, FREQ, ELECT	CV-2821/G	S	0870
5895-00-436-0054	FE1-4.5	CONV, FREQ, ELECT	CV-2821/G	S	0870
5895-00-436-0055	SM-9401A	INDICATOR, PAN			
5895-00-449-9261	MTF-100	TUNER FRAME			
5895-00-481-4663	EF-201A	EQUIPMENT FRAME			
5895-00-481-4663	EF-201C	EQUIPMENT FRAME	MT-4756/UR		
5895-00-481-4663	EF-201D	EQUIPMENT FRAME		A	0185
5895-00-481-4663	EF-201D	EQUIPMENT FRAME		A	0185
5895-00-482-5348	525A	RECEIVER, RADIO	R-1757/USQ-54(V)	S	0572
5895-00-494-0033	350A	RECEIVER, RADIO	R-1449/WLR-6(V)		
5895-00-494-0201	FC-603	CONV, FREQ, ELEC	CV-2269/WLR-6(V)		
5895-00-499-9255	MTF-101	TUNING FRAME, MI	P/00A-8899/GRR	F	1175
5895-00-615-2449	MTF-100A	TUNING FRAME, MI	P/00A-8899/GRR	F	1075

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
5895-00-824-9936	DRO-50	COUNTER, FREQ	ID-1457/G	S	0966
5895-00-824-9936	DRO-50	COUNTER, FREQ	ID-1457/G	S	0966
5895-00-851-4512	RS-138	CONVERTER, GROUP	AN/GRA-108		
5895-00-851-4514	RFE-1-4.5	CONV, FREQ, ELECT	CV-2424/UR	S	0368
5895-00-851-4514	RFE-1-4.5	CONV, FREQ, ELECT	CV-2424/UR	S	0368
5895-00-851-4517	RFE-TC	CONTROL, CONVERT	C-7642/GRA-108	S	0368
5895-00-851-4517	RFE-TC	CONTROL, CONVERT	C-7642/GRA-108	S	0368
5895-01-025-8124	SD-104A-5	DEMODULATOR			
5895-01-027-7374	WJ-9217	CONV, FREQ, ELECT	CV-2269B/WLR-6(V	N	1274
5895-01-028-1186	HT-10-3	CONV, FREQ, ELECT	CV-3257A/UR	S	0876
5895-01-028-1187	VT-11-3	CONV, FREQ, ELECT	CV-3258A/UR	S	0876
5895-01-028-1409	SWP-125-2	SWITCHING UNIT	SA-2149/UR	S	0876
5895-01-060-6492	WJ-8640-1	RECEIVER, RADIO	R-()/GRR/(V)	M	0380
5895-01-060-6492	WJ-8640-1	RECEIVER, RADIO	R-()/GRR/(V)	N	0380
5895-01-060-6492	AN/PRD-11	RCVG, SET, RADIO	AN/PRD-11		
5895-01-060-6492	WJ-8640-1	RECEIVER, RADIO	R-()/GRR/(V)	M	0380
5895-01-063-7307	VH-101	TUNING HEAD			
5895-01-064-7025	UH-101	TUNING HEAD			
5895-01-073-1582	WJ-9124	TUNER, RF	TN-585/GRR-8(V)	M	0380
5895-01-073-1582	WJ-9124	TUNER, RF	TN-585/GRR-8(V)	M	0380
5895-01-073-1582	WJ-9124	TUNER, RF	TN-585/GRR-8(V)	M	0380
5895-01-073-1604	WJ-9180-1	INDICATOR, PAN	IP-1355/GRR-8(V)	M	0380
5895-01-073-1604	WJ-9180-1	INDICATOR, PAN	IP-1355/GRR-8(V)	M	0380
5895-01-073-1604	WJ-9180-1	INDICATOR, PAN	IP-1355/GRR-8(V)	M	0380
5895-01-073-6839	WJ-8640/BC	POWER SUPPLY-BATT	PP-7566/GRR-8(V)	M	0380
5895-01-073-6839	WJ-8640/BC	POWER SUPPLY-BATT	PP-7566/GRR-8(V)	M	0380
5895-01-073-6839	WJ-8640/BC	POWER SUPPLY-BATT	PP-7566/GRR-8(V)	M	0380
5895-01-075-3694	WJ-9120	TUNER, RF	TN-586/GRR-8(V)	M	0380
5895-01-075-3694	WJ-9120	TUNER, RF	TN-586/GRR-8(V)	M	0380
5895-01-075-3694	WJ-9210	TUNER, RF	TN-586/GRR-8(V)	M	0380
5895-01-075-6391	WJ-9121	TUNER, RF	TN-584/GRR-8(V)	M	0380
5895-01-075-6391	WJ-9121	TUNER, RF	TN-584/GRR-8(V)	M	0380
5895-01-075-6391	WJ-9121	TUNER, RF	TN-584/GRR-8(V)	M	0380
5895-01-075-8594	WJ-8640-1*	RCVR SET, RADIO	AN/GRR-8(V)	N	0185
5895-01-075-8594	WJ-8640-1*	RCVR SET, RADIO	AN/GRR-8(V)	N	0185
5895-01-104-0487	RS-112	MICROWAVE RCV SYS			
5895-01-119-3953	WJ-8880	RCVG SET, RADIO	R-2036/SSQ-80(V)	N	0378

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
5895-01-136-4649	SVT-30C	TUNER, RF			
5895-01-165-4579	WJ-9122	TUNING HEAD ASSEMBLY			
5895-01-166-3861	WJ-8718//MIN	RCVG SET, RADIO	AN/URR-74(V)2	N	0281
5895-01-166-3861	WJ-8718//NAV	RECEIVER RADIO			
5895-01-166-3861	WJ-8718//MIN	RCVG SET, RADIO	AN/URR-74(V)2	N	0281
5895-01-167-9356	WJ-861XB/MFS	RECEIVER, SPARES			
5895-01-167-9360	WJ-861X-DRD	DISPLAY, DIGITAL			
5895-01-167-9361	WJ-861X-LOC	FREQUENCY MEMORY			
5895-01-167-9363	WJ-9310	PANEL, FRONT			
5895-01-186-2631	WJ-86178	RECEIVER, RADIO	R-5311/U		
5895-01-188-3308	WJ-8617A	RECEIVER, SCANNER			
5895-01-207-1649	WJ-9032/PD	INDICATOR, DIGITAL			
5895-01-207-5721	WJ-9032/PRE	AMPLIFIER, RADIO			
5895-01-213-9543	WJ-8618B	RECEIVER, RADIO	AN/URR-77(V)1		
5895-01-249-8069	WJ-8617/SM	RECEIVER, RADIO			
5895-01-268-5764	WJ-8617B	RECEIVER, RADIO			
5895-01-271-1524	WJ-4810/URF010	SWITCH, RADIO FREQUENCY TRANSMISSION LINE	SA-5110/TLQ-504(V		
5895-01-271-1542	WJ-4810/UPA010	AMPLIFIER, RADIO FREQUENCY	AM-5315/TLQ-504(V		
5895-01-276-9379	TN-118A/WJ-1840	TUNER, RADIO FREQUENCY			
5895-01-329-6007	WJ-4810/HPA100	AMPLIFIER	AM-5336/TLQ-504(V		
5895-01-329-6008	WJ-4810/VPA050	AMPLIFIER, RADIO			
5895-01-329-6008	WJ-4810/UPA050	AMPLIFIER	AM-5335/TLQ-504(V		
5895-01-344-7428	WJ-9518BE-9S	DEMULATOR			
5895-01-356-3995	WJ-8617B-29	TUNER, RADIO FREQUENCY			
5895-01-356-3996	WJ-8617B-24	TUNER, RADIO FREQUENCY			
5895-01-359-7739	WJ-8716-2	RECEIVER, RADIO			
5895-01-360-0854	WJ-9548/18	DEMULTIPLEXER			
5895-01-360-0854	WJ-9548/18CH	DEMULTIPLEXER			
5895-01-360-0855	WJ-8615/FEX12/ISB/PRE/	RECEIVER, RADIO			
5895-01-364-9649	TUX-518/WJ-8969	TUNER, RADIO FREQUENCY			
5895-01-379-4531	WJ-8615P	RECEIVER, RADIO			
5895-01-392-5969	WJ-4810/MRF100	SWITCH, RADIO FREQUENCY TRANSMISSION LINE	SA-5154/TLQ-504(V		
5895-01-392-6007	WJ-4810/HPA010	AMPLIFIER, RADIO FREQUENCY			
5895-01-393-3296	WJ-8607-93				
5895-01-393-3297	WJ-8607-93/FE				
5895-01-393-3880	WJ-9605	FRONT PANEL UNIT			
5895-01-393-6008	WJ-4810/VPA010	AMPLIFIER, RADIO FREQUENCY			

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
5895-01-413-7082	WJ-8615P-13	RECEIVER, RADIO			
5895-01-419-9808	WJ-8700/XMS2	MONITOR, RADIO FREQUENCY			
5895-01-419-9811	WJ-8690/AVX	COUPLER, INDICATOR			
5895-01-420-1576	WJ-8700	RECEIVER, RADIO			
5895-01-420-1577	WJ-8700/488	REMOTE CONTROL UNIT, CRYPTOLOGIC			
5895-01-420-1578	WJ-8700/XBW3	FILTER, RADIO FREQUENCY INTERFERENCE			
5895-01-420-1580	WJ-8690/FMD	DEMODULATOR			
5895-01-430-4278	WJ-8615P/PRE	RECEIVER SUBASSEMBLY			
5895-01-433-8921	WJ-9605/INTF	CABLE ASSEMBLY SET, ELECTRICAL			
5895-01-434-0375	WJ-9471/CRF/12/DU/4888	DEMODULATOR			
5895-01-434-0376	WJ-9471/DU	DEMODULATOR			
5895-01-434-2738	WJ-860X/6.4K	DEMODULATOR			
5895-01-434-2739	WJ-860X/20K	DEMODULATOR			
5895-01-434-2740	WJ-860X/75K	DEMODULATOR			
5895-01-434-2741	WJ-860X/500K	DEMODULATOR			
5895-01-434-2742	WJ-860X/2M	DEMODULATOR			
5895-01-434-2743	WJ-9548/FLX	DEMODULATOR			
5895-01-434-2744	WJ-9548/ACT2	MONITOR, RADIO FREQUENCY			
5895-01-435-7269	WJ-8996A1	RECEIVER, RADIO			
5895-01-436-8215	WJ-8986/FE/F5C	AMPLIFIER, RADIO FREQUENCY			
5895-01-436-8267	WJ-8986A/CH5	AMPLIFIER, RADIO FREQUENCY			
5895-01-437-2598	WJ-8996A/ASU	SWITCH, ANTENNA UNIT			
5895-01-441-6580	WJ-8609A-3	RECEIVER, RADIO			
5895-01-442-5660	WJ-8711	RECEIVER, RADIO			
5895-01-450-6314	WJ-8712P	RECEIVER, RADIO			
5895-01-453-6715	WJ-8996-1	DIRECTION FINDER			
5935-01-271-2147	WJ-9471/488				
5945-00-922-4150	SOR-1A	RELAY, SIGNAL OPER			
5955-00-262-7109	TXS-1	CRYSTAL UNIT SET			
5961-01-050-7788	WJ-9400	DEMODULATOR	MD-1017/WLR-6(V)		
5962-01-331-2599	WJ-8618B/FPK1	MICRO CIRCUIT SET			
5962-01-331-2600	WJ-8618B/FPK2	MICRO CIRCUIT SET			
5962-01-331-2601	WJ-8618B/FPK3	MICRO CIRCUIT SET			
5962-01-331-2602	WJ-6818B/FPK4	MICRO CIRCUIT SET			
5962-01-331-2603	WJ-8618B/FPK4A	MICRO CIRCUIT SET			
5962-01-331-2604	WJ-8618B/FPK4B	MICRO CIRCUIT SET			
5962-01-331-2605	WJ-8618B/FPK4C	MICRO CIRCUIT SET			

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
5962-01-331-2606	WJ-8618B/FPK5A	MICRO CIRCUIT SET			
5962-01-331-2607	WJ-8618B/FPK5B	MICRO CIRCUIT SET			
5962-01-331-2608	WJ-8618B/FPK5C	MICRO CIRCUIT SET			
5962-01-331-2609	WJ-8618B/FPK5D	MICRO CIRCUIT SET			
5962-01-331-2610	WJ-8618B/FPK5E	MICRO CIRCUIT SET			
5962-01-331-4160	WJ-8618B/FPK5	MICRO CIRCUIT SET			
5975-00-246-8592	EF-602	EQUIPMENT FRAME			
5975-01-207-1246	WJ-9032/SWP	PANEL SWITCHING			
5975-01-207-1543	WJ-9032/RACK	RACK, ELECTRICAL			
5975-01-207-1544	WJ-9032/EF	RACK, ELECTRICAL			
5975-01-344-3169	WJ-9472/CRF	RACK, ELECTRICAL			
5985-00-449-9246	TH-480C	TUNING UNIT, RF	P/00A-8899/GRR	F	1175
5985-00-449-9254	TH-245C	TUNING UNIT, RF	P/00A-8899/GRR	F	1175
5985-00-615-2448	MTF-102A	TUNER FRAME			
5985-01-203-9918	WJ-9880-4	ANTENNA	AS-3778/G	A	0185
5985-01-203-9918	WJ-9880-4	ANTENNA	AS-3778/G	A	0185
5985-01-207-1415	WJ-9873	ANTENNA			
5985-01-304-6221	796787-1 (Part of WJ-9880)	ANTENNA ARM ASSEMBLY			
5995-00-191-2655	EC-425	CABLE ASSEMBLY SPEC			
5995-01-326-5889	WJ-8518/DFC	CABLE ASSEMBLY			
5998-01-325-2884	WJ-8618/ASO	CIRCUIT CARD ASSY			
5998-01-325-2885	WJ-8618B/DAV	CIRCUIT CARD ASSY			
5998-01-325-5578	WJ-8618/WBO	CIRCUIT CARD ASSY			
5998-01-325-5579	WJ-8618B/LFE	CIRCUIT CARD ASSY			
5998-01-325-9645	WJ-8518/EM	CIRCUIT CARD ASSY			
5998-01-325-9647	WJ-8618B/CUR	CIRCUIT CARD ASSY			
5998-01-325-9648	WJ-8618/RTC	CIRCUIT CARD ASSY			
5998-01-345-1537	WJ-9946				
5998-01-354-2859	WJ-8607/FE07	FREQUENCY EXTENDER			
5999-01-167-9397	WJ-8971A	ELECTRONIC COMPONENT			
5999-01-204-5034	WJ-9470/CRF12	CHASSIS, ELECTRICAL			
5999-01-268-7192	WJ-9472/SMU				
5999-01-274-6648	WJ-9472/488				
5999-01-293-8730	370094-1 (Part of WJ-9880)				
5999-01-325-9577	WJ-8618/WBO-2	CIRCUIT CARD ASSY			
5999-01-346-1681	WJ-9908	CHASSIS, ELECTRICAL			
6605-01-271-3489	PTS-500X	FREQUENCY SYNTH			

NSN	WJ Equip No	Description © 2008 by Terry O'Laughlin	Nomenclature	Serv	Date
6615-01-238-9857	WJ-9470	DEMODULATOR			
6615-01-257-8955	WJ-9477	DEMODULATOR			
6625-00-042-6768	DRO-310	COUNTER, FREQ	CP-943/GLA-21	A	0568
6625-00-049-7830	DRO-309-1	COUNTER, FREQ			
6625-00-049-7833	SM-9304A	INDICATOR, PAN			
6625-00-262-1045	DRO-309B	COUNTER, FREQ			
6625-00-262-1045	DRO-309A	COUNTER, FREQ	CP-1226/UR	F	0873
6625-00-262-1046	TS-401	TEST SET, ELE			
6625-00-342-1854	DRO-300A	FREQ COUNTER			
6625-00-400-1846	DRO-290A	COUNTER, FREQ	CP-982/G	S	0269
6625-00-400-1846	DRO-290A	COUNTER, FREQ	CP-982/G	S	0269
6625-00-408-8843	DRO-308	COUNTER, FREQ	CP-1056/GR	S	0770
6625-00-500-6638	DRO-302A-2	COUNTER, FREQ			
6625-00-931-9451	AN/GLA-21	FREQ MEASURING SET			
6625-01-012-4167	IFD-103	DEMODULATOR, IF			
6625-01-014-1712	DRO-333	COUNTER, FREQ			
6625-01-041-4450	DMS-107-1	PROCESSOR, SIGNAL			
6625-01-093-7003	DRO-315	FREQ, COUNTER			
6625-01-135-3929	DRO-333A	FREQ, COUNTER			
6625-01-155-0162	DRO-320-1	FREQ, COUNTER			
6625-01-293-0394	WJ-8999	TEST RECEIVER			
6625-01-293-3094	WJ-8999	ANALYZER, SPECTRUM			
6625-01-344-4424	WJ-9207	PAN DISPLAY			
6675-01-G594679	J-277	COMPASS			
7025-00-482-5347	DRO-306A	COUNTER, FREQ	CP-1087/USQ-54(V)	S	0572
7025-01-066-7776	EC-401	EXTENDER CABLE			
7025-01-067-1385	441-6A-32	RECEIVER, RADIO			
7045-01-419-9807	WJ-8690-CTS	TAPE, ELECTRONIC DATA PROCESSING			
7050-00-828-1854	IFD-50	DEMODULATOR, IF			
7050-01-022-9605	IFD-201	DEMODULATOR, IF			